



## COVERING MATERIALS

### TRAVEL AIR WINGS

#### SYSTEM VI

Quantity		Part Number	Description
36	Yd.	SF102	2.7 oz. Certified Fabric
2	Qt.	U500-04	Urethane Adhesive
1	Gal.	SF-MEK	Methyl Ethyl Ketone
1	Gal.	Superwash	Fabric Cleaner
2	Roll	SF102-2P	2" Pinked Edge Surface Tape
1	Roll	SF102-3P	3" Pinked Edge Surface Tape
1	Roll	SF-REINF 1/2"	1/2" Reinforcement/Anti Chafe Tape
1	Pkg	L274	Drain Grommets
1	Roll	SF694-500	Flat Rib Lacing Cord
2	Gal.	SF6500-01	Fabric Primer Base
16	Pt.	SF6600-08	Fabric Primer Catalyst
8	Pt.	SF6700-08	Fabric Primer Flex Agent
2	Gal.	SF6820-01	Primer & Paint Reducer
2	Gal.	Superthane	System VI Urethane Topcoat
4	Pt.	SF6950-08	Topcoat Catalyst

#### optional materials:

Pre-shrunk Fabric tapes  
KA25B25 Gluemaster Glue Gun  
Coverite Iron  
Calibrating thermometers  
Invisible Gloves  
Viscosity Cups  
Paint Strainer Cones  
Tyvek Paint Suit  
D-102 System VI Covering Manual